


# **Installation** Instruction








- Read all instructions to prevent injury, electric shock or damage due to fire or mechanical hazards.
- See product label for supply specifications.
- Suitable for direct mounting on flammable surfaces.

#### **STORAGE:**

Prior to installation products are to be stored in cool and dry conditions.



4x mounting holes on both ends

BY A LICENSED ELECTRICIAN







### **Cautions:**

- Installation is to be completed by an competent licenced electrician, in accordance with these instructions and relevant local regulations.
- Electronic control equipment must not be subjected to high voltages, DO NOT MEGGER between Live and Neutral.

**Mounting Distance** 

960

- All cable/conduit terminations must be installed in accordance with the designated IP rating of this product.
- Suitable installation fastening methods should be employed to ensure the mounting points are not damaged when subjected to vibration and or movement.

## Installation:

Open the gear cover and install the fitting direct to the ceiling through four mounting holes provided.

1) Loosen both gear cover screws

2) Lift up by sliding the gear tray cover



## **Mains Connections:**

Bring in the mains supply cables through cable entry hole and connect them to the terminal block located in the gear compartment.

WARNING: This product must be earthed.

